

READYLIFT™

LEVELING SUSPENSION

ReadyLift™ Part # 66-2090 Installation Instructions

2005-2006 Ford F250 / F350 4x4

Please read instructions thoroughly and completely before beginning installation.

Installation by a trained mechanic is recommended.

Step 1:

Position truck on a flat surface and block the rear wheels to keep it stable. Starting on the driver side remove the stock shock absorber and retain hardware.

Note: New longer front shocks will be needed for this installation. Ready lift recommends a shock that measures 23" fully extended.



Step 2:

Continuing on the drivers' side, remove the stock sway bar frame mount, retain the hardware for re-installation.

Step 3:

Next remove the stock brake line bracket from the bottom of the stock coil spring, retain the hardware for re-installation.

Step 4:

Scribe a mark on the lower coil spring plate as well as the coil spring. This is done to re-install the coil in the exact location.

(Repeat Steps 1 thru 4 on passenger side of vehicle)

Step 5:

Place a pair of hydraulic jacks under the frame on both sides of vehicle. With a second persons help, raise the vehicle until the top of the coil springs are separated from the upper coil location. Keep raising jacks until coils can be removed



READYLIFT™

LEVELING SUSPENSION

ReadyLift™ (66-2090) Installation Instructions

Step 6:

Locate the new coil spring spacers and the new isolators. Install the spacers on the top of the drivers side coil spring and the isolators on the top of the new spacers. Holding the drivers side coil in its stock location (Lining up the marks from step 5). Lower jack until coil, spacer and isolator seat properly into the stock spring location.



Step 7:

Reinstall all hardware and components removed during Steps 1 thru 4. Be sure to re-torque all hardware to the proper settings. (Use of a thread locker like lock tight is recommended). Re Install Wheels and Tires

Wheel Alignment; a Certified Alignment Technician that is experienced with lifted vehicles is recommended to perform the alignment.

*It is recommended that you have your vehicle's alignment checked whenever installing new tires.

*It is also recommended that you adjust your headlights whenever your vehicle's ride height is altered.



Vehicle Handling Warning

Vehicles with larger wheels and tires will handle differently than stock vehicles. Take time to familiarize yourself with the handling of your vehicle.

DRIVE SAFELY and WEAR YOUR SEATBELT.

Installation Warning

Always wear proper safety equipment and use the correct tools when installing any suspension upgrade. Make sure vehicle is on a flat surface and you are using jack stands or a lift rated for the weight of the vehicle.

Warning! This ReadyLift™ Leveling Kit is designed and engineered to level out a stock vehicle with no prior modifications. The use of this kit along with items such as rear lift blocks or spacers, add a leafs, airbags, suspension lifts, body lifts or any other type of lifting accessory shall be done at the vehicles owners risk and will void any and all warranties in effect or implied by ReadyLift™

ReadyLift™
1000 Bristol Street North,
Suite 17-168
Newport Beach, CA 92660

Toll Free 800-549-4620
949-515-0795
Fax 949-515-0655