

ReadyLift™ (Part# 66-3070) Installation Instructions

2006 Hummer H3/2005-2007 Colorado/Canyon 4wd

Please read instructions thoroughly and completely before beginning installation.

Installation by a trained mechanic is recommended

Step 1:

Position truck on a flat surface and lift vehicle by the frame so that the front wheels are off the ground using a floor jack and jack stands or a (2) two post lift if available.

First, remove driver side front wheel, then unbolt upper shock mounting nut.(A) Next remove lower shock mounting nut and bolt.(B) Remove shock. Install shock stem spacer provided and reinstall bushings and shock.(C) & (D) Verify that all fasteners have been tightened to the proper torque specs and re-install wheel.

*Be sure to torque the lug nuts to the proper OEM settings.



(A)



(C)



(B)



(D)

ReadyLift™ (Part# 66-3070) Installation Instructions 2006 Hummer H3/2005-2007 Colorado/Canyon 4wd

Step 2:

Replace Torsion Key

Remove stock torsion key. Bolt is located in cross-member beneath the doors. Please note that the factory keys are a left and a right and you need to match up the offset key to each one. Install ReadyLift™ torsion key.



(E)



(F)

Step 3:

Repeat steps 1 & 2 on the Passenger Side of the vehicle. Follow each step closely making sure to double check the torque on all fasteners.

Step 4:

Wheel Alignment; a Certified Alignment Technician that is experienced with lifted vehicles is recommended to perform the alignment.

*It is recommended that you have your vehicle's alignment checked whenever installing new tires.

*It is also recommended that you adjust your headlights whenever your vehicle's ride height is altered.

READYLIFT™

LEVELING SUSPENSION

ReadyLift™ (Part# 66-3070) Installation Instructions 2006 Hummer H3/2005-2007 Colorado/Canyon 4wd



Before ReadyLift™



After ReadyLift™

Vehicle Handling Warning

Vehicles with larger wheels and tires will handle differently than stock vehicles.

Take time to familiarize yourself with the handling of your vehicle.

DRIVE SAFELY and WEAR YOUR SEATBELT.

Installation Warning

Always wear proper safety equipment and use the correct tools when installing any suspension upgrade. Make sure vehicle is on a flat surface and you are using jack stands or a lift rated for the weight of the vehicle.

Warning! This ReadyLift™ Leveling Kit is designed and engineered to level out a stock vehicle with no prior modifications. The use of this kit along with items such as rear lift blocks or spacers, add a leafs, airbags, suspension lifts , body lifts or any other type of lifting accessory shall be done at the vehicles owners risk and will void any and all warranties in effect or implied by ReadyLift™.

ReadyLift™

1000 Bristol Street North, Suite 17-168, Newport Beach, CA 92660
Toll Free (800)549-4620 Local (949)515-0795 Fax (949)515-0655