

READYLIFT™

LEVELING SUSPENSION

ReadyLift™ Part# 66-5055 Installation Instructions

2005-7 Toyota Tacoma 2wd / 4wd 2.25" Leveling Kit

Please read instructions thoroughly and completely before beginning installation

Position truck on a flat surface and lift the front wheels off the ground. Use jack stands or a (2) two post lift if available, and remove both front wheels.

Starting from the passenger side, remove the sway bar end link nuts on both sides of truck,
Insert A



Insert A



Insert B

Remove bolts holding the front of the sway bar. *Insert B*

Remove ABS bracket bolts on the knuckle and upper a-arm.
Insert C



Insert C

Remove the cotter pin and loosen but **Do Not Remove** the upper ball joint nut. Use of a hammer to break the ball joint free may be needed
Insert D



Insert D

READYLIFT™

LEVELING SUSPENSION

ReadyLift™ Part# 66-5055 Installation Instructions

Remove the three upper strut mounting bolts. Remove the lower strut mounting bolt,
Insert E

It is recommended that you complete one side of the installation before starting the second side.



Insert E

Step 2

Remove the strut from the vehicle and mount it in a bench vise. Install the ReadyLift™ kit, and torque fasteners to OEM specifications.

Note the shape of the ReadyLift™ spacer; the strut will be rotated 180 degrees when reinstalled.



READYLIFT™

LEVELING SUSPENSION

ReadyLift™ Part# 66-5055 Installation Instructions

Step 3:

Reinstall the strut assembly in its stock location, and re-install upper ball joint.

*It may be necessary to push the lower a-arm **down** to aid in the re-installation of the strut assembly, and a floor jack to raise the lower a-arm **up** in order to get the upper ball joint bolt installed.

Re-attach ABS line brackets.



Step 4:

Repeat steps 1 through 3 on the Driver's Side of the vehicle. Then re-install the sway bar nuts and bolts on both sides after the upper ball joints have been re-attached. Follow each step closely, making sure to double check the torque on all fasteners.

READYLIFT™

LEVELING SUSPENSION

ReadyLift™ Part# 66-5055 Installation Instructions

Step 5:

Wheel Alignment; a certified alignment technician that is experienced with lifted vehicles is recommended to perform the alignment.

*It is recommended that you have your vehicle's alignment checked whenever installing new tires

*Adjust your headlights whenever your vehicle's ride height is altered.



Before



After

Vehicle Handling Warning

Vehicles with altered suspensions will handle differently than stock. Take time to familiarize yourself with the new handling of your vehicle.

DRIVE SAFELY AND WEAR YOUR SEATBELT.

Installation Warning

Always wear proper safety equipment and use the correct tools when installing any suspension upgrade. Make sure vehicle is on a flat surface and you are using jack stands or a lift rated for the weight of the vehicle.

Warning! This ReadyLift™ Leveling Kit is designed and engineered to level out a stock vehicle with no prior modifications. The use of this kit along with items such as rear lift blocks or spacers, add a leafs, airbags, suspension lifts, body lifts or any other type of lifting accessory shall be done at the vehicles owners risk and will void any and all warranties in effect or implied by ReadyLift™