



WeatherTech®
WeatherFlectors™

INSTALLATION INSTRUCTIONS, REAR CAB WINDOW

Installation is recommended at
temperatures above 50°
Fahrenheit.

1 Clean Installation Area



Dry fit the WeatherFlector™ on the window. Clean the installation area of the glass with the included alcohol wipe. Dry with enclosed wipe. NOTE: Glass must be cleaned for the WeatherFlector™ to stick properly.

2 Remove Tape Backing



Remove the red tape backing from the WeatherFlector™. Peel the tape backing from one end to the other. Avoid touching the adhesive to keep it clean.

3 Attach WeatherFlector™



Carefully align the WeatherFlector™ along the top of the window. Press the WeatherFlector™ to the window. Make sure the entire length of the tape makes contact with the window surface.

4 Finishing Up



Press and hold the WeatherFlector™ firmly in place for at least 30 seconds to ensure a proper attachment to the window. Important: Avoid rain or washing vehicle for at least 72 hours to allow good adhesion.

Repeat steps (1) through (4) for passenger-side window installation.

Questions? Call customer service @ 1.630.769.1500
Monday — Friday, 9 a.m. — 5 p.m. central time.

